## Charnwood W586 Parts List

## Part no. Description

- Motor 1.
- 2. Flat washer
- 3. Spring washer
- 4. Socket head screw
- 5. Main driving pulley wheel
- 6. Nut M5
- 7. Adjust chain wheel
- 8. Chain
- "C" ring 9.
- 10. Chain fastener sleeve
- 11. Chain fastener rivet
- 12. Feed direction indicator
- **13**. Rivet
- 14. Main screw mandrel
- 15. Driven screw mandrel
- 16. Nut M6
- 17. Spring washer 6
- 18. Flat washer 6
- 19. Thicknessing table set
- 20. Guiding plate
- 21. Socket head screw
- 22. Socket head screw
- 23. Slider
- 24. Extended table parts
- 25. Cable clamp
- 26. Socket head screw
- 27. Rubber feet
- 28. Nut M8
- 29. Star washer
- 30. Flat washer
- 31. Spring washer
- **32**. Cross pan headed screw
- 33. Screw base
- 34. Switch box
- 35. Pan headed screw M5x8
- 36. 12A overload protector
- 37. Switch box cover
- 38. Self-tapped screw
- 39. Main switch
- **40**. Body cover
- 41. Main label
- 42. Cap nut
- 43. Belt
- 44. Wheel
- 45. "O" rina
- 46. Washer


## Part no. Description

- Small chain wheel 47.
- 48. Big gear
- 49. Square sleeve
- Connecting board **50**.
- 51. Pressing block
- **52**. Spring
- Dividing sleeve **53**.
- **54**. Chain
- 55. Chain
- Socket head screw 56.
- 57. Wire - interlock switch
- **58**. Split washer
- **59**. **Eccentric** spindle
- 60. Wire of micro switch
- 61. Wire anchor
- **62**. Connecting pole A
- 63. Cross pan head screw
- Flat washer 64.
- 65. Interlock switch
- 66. Cross pan head screw
- 67. Nut M3
- 68. Cross pan head screw
- 69. Socket head screw
- **70**. Interlock switch
- 71. Washer
- **72**. Interlock switch
- 73. Planer Feed guide label
- 74. Switch cover
- **75**. Switch trigger
- **76.** Semi-rounded rivet
- **77**. Body cover parts
- **78.** Needle bearing
- **79**. Bearing housing
- 80. Socket head screw
- 81. socket head screw
- 82.
- Big flat washer
- 83. Big chain wheel
- 84. Spring
- 85. Pulley wheel
- 86. main shaft
- 87. Spring
- 88. Blade base set
- 89. Baffle
- 90. Crank support
- 91. Knob of crank
- 92. Stopple

- **93.** Screw
- **94.** Locking nut
- **95.** Pull stick
- **96.** Adjusting pole
- **97.** Knob
- **98.** Pan headed screw
- 99. Arm stopple
- **100.** Fixing board
- **101.** Self-tapped screw
- **102.** Locating pivot pin

- **103.** Plastic stopple
- **104.** Self-tapped screw
- **105.** Blade guard
- 106. locker
- **107.** Limiting screw
- **108.** Semi-rounded rivet
- **109.** Limiting screw pole
- **110.** Knob
- **111.** Guard arm connector
- **112.** Locking sleeve

## **Charnwood W586 Exploded View Diagram**



11