



W820 Lathe Parts Diagram



1	Spur center	1	44	Tailstock	1
2	Face plate	1	45	"C" ring	1
3	Key	1	46	Washer	1
4	Spindle	1	47	Lead screw	1
5	Ball bearing	1	48	Scale ruler	1
6	"C" ring	1	49	Quill	2
7	Hex socket	4	50	Center	1
8	Washer	4	51	Tool rest	1
9	Spring washer	4	52	"C" ring	1
10	Cover plate	1	53	Handle	1
11	Washer	1	54	Tool rest base	1
12	Screw	1	55	Lever	1
13	Plate	1	56	Lever cover	2
14	Screw	1	57	Bushing	2
15	Belt	1	58	"C" ring	1
16	Set screw	1	59	Clamp bolt	1
17	Spindle pulley	1	60	Clamp bolt	1
18	Ball bearing	1	61	Nut	1
19	Set screw	2	62	Strain relief	1
20	Cover	1	63	Plate	1
21	Handle	1	64	Screw	3
22	Hinge	1	65	Base	1
23	Washer	3	66	Washer	1
24	Screw	3	67	Cap screw	1
25	Nut	3	68	Motor pulley	1
26	Washer	1	69	Nut	1
27	"C" ring	4	70	Set Screw	1
28	Headstock	1	71	Motor plate	1
29	Switch base	1	72	Handle	1
30	Screw	4	73	Washer	1
31	Switch	1	74	Handle	1
32	Screw	2	75	Motor	1
33	Handle	1	76	Wrench	1
34	Set screw	1	77	Knockout bar	1
35	Handle	2	78	Strut-A	1
36	Hex socket	1	79	Strut-B	1
37	Hand wheel	1	80	Display	1
38	Lever	1	81	Screw	4
39	Lever cover	1	82	Velometer	1
40	Nut	1	83	Nut	2
41	Clamp		84	Bracket	1
42	Spring	1	85	Sensor	1
43	Clamp bolt	1	86	Screw	2

Parts Diagram